



BROOM CENTER & WASH CENTER INSTALLATION INSTRUCTIONS

Hardware Required: For wood walls – 3/8” x 2” lag screws. For concrete – 3/8” x 1-7/8” sleeve type anchor bolt.

Tools Required: 7/16” socket with ratchet, 9/16” and 1/2” sockets with ratchet, drill with 3/8” masonry bit or 1/4” wood bit, stud finder, level and tape measure.

Step 1: Determine the mounting position for grid panel. Consider the longest item to be stored on the system to determine mounting height. For average length items, mount with the bottom of the grid panel 60” above the floor.

Step 2: For a 60” mounting height, measure from the floor up 58-1/2” and make a mark on the wall. Using a level, draw a level horizontal line on the wall. With a straight edge, extend the length of this line to about 48”.

Step 3: If mounting on a wood stud wall, find two studs 48” apart and mark the stud centers on the horizontal line. If mounting on a concrete block wall, locate the center of two concrete blocks that are around 48” apart and mark these two points on the horizontal line.

Step 4: Drill holes in the wall at these two points and loosely mount two wall mount brackets supplied using the appropriate hardware for your wall type.

Step 5: Install the bottom of the grid panel into these brackets. Have an assistant hold the grid panel in place. Install the top two wall mount brackets on the top of the grid panel directly above the bottom brackets.

Step 6: Adjust the horizontal position of the grid panel if desired and securely tighten the hardware holding the wall mount brackets. **Make sure the hardware is securely installed in your wall surface. Improper installation may cause injury.**

Step 7: Clip the broom and brush holders onto grid and load rack.